
INSTALLATION INSTRUCTIONS

PT-LS-HO Series


PT-LS-HO-4F-3CP / PT-LS-HO-8F-3CP






INSTALLATION (ALWAYS TURN OFF THE POWER SUPPLY FROM MAIN CIRCUIT BREAKER FIRST!)

CCT AND WATTAGE SELECTOR



• DIP switches are located onto the drive box.

• Select a wattage and color temperature by sliding switch left or right respectively to the desired value.







PT-LS-HO Series

PT-LS-HO-4F-3CP / PT-LS-HO-8F-3CP



SUSPENDED MOUNTING






Figure A

Figure B

Figure C



IF EMERGENCY COLOR TEMPERATURE IS 5000K



IF EMERGENCY COLOR TEMPERATURE IS 3500K

