# INSTALLATION INSTRUCTIONS

# **PT-DLR-G SERIES**

PT-DLR-G-4I / PT-DLR-G-6I





# **CAUTION: RISK OF ELECTRIC SHOCK**

DISCONNECT POWER BEFORE CONNECTING THE FIXTURE. FAIL TO DO SO MAY PERMANENTLY DAMAGE THE LEDS.

WARNING

6" (1 pc)

DO NOT REMOVE OR ATTEMPT TO REMOVE LEDS.

# **SAFETY PRECAUTIONS**

FOR SAFETY, READ AND UNDERSTAND INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION. ELECTRICITY SHOULD BE TURNED OFF AT THE FUSE OR THE CIRCUIT BREAKER BOX BEFORE INSTALLING THE FIXTURE, ALL ELECTRICAL CONNECTIONS MUST BE IN ACCORDANCE WITH N. E. C. OR YOUR LOCAL CODE

# ASSEMBLY INSTRUCTIONS

- 1 PREPARING FOR INSTALLATION: DISCONNECT ELECTRICAL POWER REFORE INSTALLING OR SERVICING ANY PART OF THIS FIXTURE
- 2. THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED. INCLUDING THAT MAY CAUSE UNDESIRED OPERATION.

# PACKAGE CONTENTS A LED Retrofit Downlight **B** E26 lamp holder

4" (1 pc)

# **INSTALLATION** (CONSULT A QUALIFIED ELECTRICIAN BEFORE INSTALLING)


## STEP 1


Remove the existing lamps and trim. (Fig. 1)

## STEP 2

Screw the E26 connector piece into the existing socket. (Fig. 2)

Select the desired color temperature on the back of the fixture. (Fig. 3)







(1 pc)

Fig. 2


Fig. 3

# FOR 4" HOUSING:

## STEP 4

Connect the terminals from E26 socket to fixture. (Fig. 4)

Push fixture up into can, ensuring it is flush with ceiling. (Fig. 5)






Fig. 4

### FOR 5" OR 6" HOUSING:

### STEP 6

Set spring clip in the proper position to fit into either a 5" or 6" housing by loosening screw, moving the spring, and then re-tightening.

# STEP 7

Connect the terminals from E26 socket to fixture. (Fig. 6)

Press spring clips together, push fixture up into can until fixture is secure. (Fig. 7)

www.portorlighting.com






Fig. 7

Fig. 6

