

INSTALLATION INSTRUCTIONS

PT-WPA SERIES

PT-WPA-HW-3CP / PT-WPA-MW-3CP

PORTOR
LIGHTING
a PORTOR INDUSTRY brand



READ THESE INSTRUCTIONS COMPLETELY AND CAREFULLY

SAFETY

THIS FIXTURE MUST BE WIRED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE AND APPLICABLE LOCAL CODES AND ORDINANCES. PROPER GROUNDING IS REQUIRED TO INSURE PERSONAL SAFETY. CAREFULLY OBSERVE THE GROUNDING PROCEDURE UNDER INSTALLATION SECTION. ALL WORK SHOULD BE DONE BY A QUALIFIED ELECTRICIAN.

- **RISK OF ELECTRIC SHOCK** - DISCONNECT POWER AT FUSE OR CIRCUIT BREAKER BEFORE INSTALLING OR SERVICING.
- **RISK OF PERSONAL INJURY** - FIXTURE MAY BECOME DAMAGED AND/OR UNSTABLE IF NOT INSTALLED PROPERLY. TIGHTEN ALL FIXTURE COMPONENTS TO THEIR RECOMMENDED TORQUE VALUES.

WARNING


- TURN OFF ELECTRICAL POWER AT FUSE OR CIRCUIT BREAKER BOX BEFORE WIRING FIXTURE TO THE POWER SUPPLY.
- TURN OFF THE POWER WHEN YOU PERFORM ANY MAINTENANCE.
- VERIFY THAT SUPPLY VOLTAGE IS CORRECT BY COMPARING IT WITH THE LUMINAIRE LABEL INFORMATION.
- ALL WIRING CONNECTIONS SHOULD BE CAPPED WITH UL APPROVED WIRE CONNECTORS.

CAUTION


- AVOID DIRECT EYE EXPOSURE TO THE LIGHT SOURCE WHILE IT IS ON.
- ACCOUNT FOR SMALL PARTS AND DESTROY PACKING MATERIAL, AS THESE MAY BE HAZARDOUS TO CHILDREN.
- **RISK OF BURN.** DISCONNECT POWER AND ALLOW FIXTURE TO COOL BEFORE CHANGING BULB OR HANDING FIXTURE.

INSTALLATION (ALWAYS TURN OFF THE POWER SUPPLY FROM MAIN CIRCUIT BREAKER FIRST!)


1. Fix the junction box on the wall. (Fig 1)





2. Fix the Eight Trigrams Plate on the Terminal Box. (Fig 2)



3. Hook the guide lock of the entire lamp onto the gossip tray. (Fig 3)




4. Connect the corresponding terminals according to the wiring diagram, connect L, N, and ground wires properly. (Fig 4)




INSTALLATION (ALWAYS TURN OFF THE POWER SUPPLY FROM MAIN CIRCUIT BREAKER FIRST!)

5. Hide the connected wires into the junction box and hook the lamp body onto the gossip board. (Fig 5)



6. Fix the lamp body and the Eight Trigrams Plate with screws. (Fig 6)



WATTAGE & CCT SELECTOR GUIDANCE


FACTORY DEFAULT SETTING:

WATT: 60W/100W

CCT: 5000K

PHOTOCELL: ON

Easily flip the switch for desired CCT and Wattage



<input type="checkbox"/>	W = 60	100
<input checked="" type="checkbox"/>	W = 48	80
<input type="checkbox"/>	W = 36	60